Touchscreen Radio Aid System

The radio aid transmitter should be used during teacher input.

Transmitter: (Worn by speaker)

The hearing aid will pick up the radio signal sent by the transmitter. This means that she hears a clear version of your voice when you talk.



Microphone, worn 15 cm from your mouth. You can alter the length of the lanyard around the neck. Ensure that other lanyards do not 'knock' against the radio aid

Switch on/off



Place the microphone near the hearing aid to connect. Message will say "Roger x is connected."

Microphone Mute button. Press to mute the microphone (flashes red). Press to reactivate the microphone again (flashes green).

Use the microphone mute switch to turn your voice on and off during a session.
The signal sent by the transmitter will adjust to your voice level and to the level of background noise.
There is an audio socket on the base that can be used to plug the transmitter into any audio output socket on other equipment e.g. headphone socket on a computer.
*For optimum performance, ensure the microphone is not blocked or covered. Remember to turn off or mute the microphone if you are leaving the room or no longer speaking to the student

BELS
Barnet Education & Learning Service