Roger On System

The microphones must not be covered or disturbed and should be placed approx. 20cm from the speaker's mouth

On / off button

The Roger On has a clip that can be clipped to the speaker's clothing and also has a lanyard option

Hold this button down for 2 seconds to mute / unmute.

Can also be used to change programmes (quick push, managed by student)

Press this button each time the Roger On is turned on, to connect to hearing aids (hold next to hearing aids, managed by student)







Charging point – please leave on charge every evening. Can also be used to connect to laptop using the jack cable supplied.

Use the microphone mute switch to turn your voice on and off during a session.

The signal sent by the transmitter will adjust to your voice level and to the level of background noise.

*For optimum performance, ensure the microphone is not blocked or covered. Remember to turn off or mute the microphone if you are leaving the room or no longer speaking to the student