Edu Mic System

LED lights.
Green – on.
Flashing green - mute

The microphone must not be covered or disturbed and should be placed approx. 20cm from the speaker's mouth

On / off / mute button – press the button briefly to switch between on / mute / off

The mini mic has a clip that can be clipped to the speaker's clothing and also has a lanyard option



Micro charging – please leave on charge every evening

Can also be connected to an audio device such as a laptop using the jack cable supplied

Use the microphone mute switch to turn your voice on and off during a session.

The signal sent by the transmitter will adjust to your voice level and to the level of background noise.

There is an audio socket on the base that can be used to plug the transmitter into any audio output socket on other equipment e.g. headphone socket on a computer. Use the lead provided.

*For optimum performance, ensure the microphone is not blocked or covered. Remember to turn off or mute the microphone if you are leaving the room or no longer speaking to the student